

Pinch & Roller Crowbars

A simple tool for lifting and manoeuvring small machines or office furniture.



Code 70510 / 70520

NEVER allow yourself or others to be in a position between the load and a wall or other fixed structures as you could become trapped and seriously injured.

Take your time and don't overdo it. You are more likely to have an accident if you are tired or rushing.

EQUIPMENT CARE

Never push the equipment beyond its design limits. If it will not do what you want with reasonable ease and speed, assume you have the wrong equipment for the job. Contact your local HSS Lift & Shift Depot for advice.

Keep the equipment clean, you will find this less of a chore if you clean it regularly, rather than wait until the end of the hire period.

When not in use, **store the equipment somewhere clean, dry and safe** from thieves and unauthorised users.

FINISHING OFF

Remove the crowbar from the load, then give the equipment a final clean up ready for return, to your local HSS Lift & Shift Depot.



... have you been trained

The law requires that personnel using this type of equipment in the workplace must be competent and qualified to do so.

Training is available at HSS Training
0845 766 7799

...any comments?

If you have any suggestions to enable us to improve the information within this guide please e-mail your comments or write to the Safety Guide Manager at the address below
e-mail: safety@hss.com

©HSS Hire Service Group Ltd 2020 No. LS47/01

76 Talbot Road, Old Trafford, Manchester, M16 0PQ

www.hss.com

GENERAL SAFETY

For advice on the safety and suitability of this equipment **contact your local HSS Lift & Shift Depot.**

There is a serious risk of personal injury if you do not follow all instructions laid down in this guide.

This equipment is designed to be used by an able bodied, competent adult who has read and understood these instructions. Anyone with either a temporary or permanent disability should seek expert advice before using it.

Keep children, animals and bystanders away from the work area. Cordon off a NO GO area using cones and either barriers or tape, available for hire from your local HSS Lift & Shift Depot.



Never use this equipment if you are ill, feeling tired, or under the influence of alcohol or drugs.



Wear practical, protective clothing, gloves and footwear. Avoid loose garments and jewellery that could catch in moving parts, tie back long hair.

Safety Warning

This equipment MUST NOT be used to carry or lift personnel.

Make sure you know how to operate this equipment safely and are aware of its limitations before you use it.

It is both the hirer's and the operator's responsibility to perform a risk assessment before using this equipment. You are also responsible for the safety of any person in the work area.

Make sure that anyone in the immediate work area is warned of what you are doing.

Be aware of the raised load when close to ceilings or other overhead obstructions.

Comm Code	SWL	Never exceed the equipment's safe working load, see chart.
70510	1,000kg	Check the condition of the equipment before
70520	1,500kg	

use. If it shows signs of damage or excessive wear, return it to your local HSS Lift & Shift Depot.

GETTING STARTED

This equipment must only be used on a surface capable of withstanding the weight of the load.

Thoroughly clear and clean the floor area to remove oil, grease and swarf.

Ensure you have selected a set of pinch or roller crowbars that are designed for the item's weight.

Have to hand, any lifting and pulling equipment needed for the job. HSS can offer for hire, various

components depending on what you are trying to achieve.

The equipment available ranges **from nylon and wire ropes, shackles, manual and hydraulic tirlor winches, to machine moving skates and toe jacks.** For advice on the range of equipment, contact your local HSS Lift & Shift Depot.

Check that the route to the destination is clear and the surface is suitable for both the weight and the pinch or roller crowbars.

Assess the load's design to determine the best position for the crowbar, the load must balance correctly on the crowbar's tongue.

The contact point of the load MUST be able to support its weight, i.e. a suitable jacking point, in the same way as jacking a car.

Determine the best position for the crowbar.


Under no circumstances must anyone allow their hands or feet under the load, when raised on the crowbar.

Next place the front tip of the crowbar's tongue under the front of the load.

The crowbar should be in a position whereby the load will be evenly distributed and safely balanced.

With the load raised on the crowbar's tongue, double check that everything is OK, make sure that the contact point between the load and crowbar is strong enough.

BASIC TECHNIQUES



The crowbar must not be steered with the load stationary, steering may only occur when the load is moving.

Attach suitable moving equipment to the load. Where the load allows, have helpers push from behind.

When the load is moving always position yourself so you can control the crowbar while staying clear of the raised load.

Continually check the path behind and in front of you to make sure there are no trip hazards.

Do not allow the load to travel at speed or change its direction of travel abruptly.

Know Your Symbols

HSS have created clear Icons to inform the hirer of their responsibilities towards the safe use of hire equipment.

These are designed to reduce the amount of different safety information labels required for each product for hire.

General use PPE / Warning

Clearly marked minimum PPE will be visible on all equipment,



Correct PPE must be worn



HAV Hand Arm Vibration



Danger Rotating blade



Danger Hot exhaust



Danger Electric shock



Caution Abrasive Wheel



Caution Finger trap

Fuel and Supply Types



Pe
Petrol



Di
Diesel



2t
2 - Stroke Petrol



EI
Electric

Safe Procedures

All hirers must understand and respect the safe procedures of all equipment.

It is the responsibility of the hirer to maintain and return the equipment in a clean condition and good working order.



Ro
Read OPS Guide



Ou
Outdoor Use only



HI
Heavy Lifting



Cd
Check Oil daily



Cf
Check Fuel daily



Cw
Check Water daily



Bc
Battery Care



Sh
Safe Height Working



Swl
Refer to Data Plate




V
Check Power Voltage Data Plate

Electrical Safety

Safe wiring procedures.



Ea
Must be Earthed Class 1



Doi
Double Insulated Class 2



Enl
Earth Live Neutral Wire Coding

Return Responsibility

Charges apply to equipment returned dirty and damaged.



Cc
Cleaning Charge



Rc
Repair Charge